

# SPOTNAILS MAESTRI



## SPOTNAILS MAESTRI GUIDE TO FIXING HANSON SP101 FLOORING PLYWOOD

### WE RECOMMEND YOU USE

SPOTNAILS DIVERGENT POINT (DC) STAPLES OR SPOTNAILS RING SHANKED SHEET COLLATED NAILS. BOTH TOOLS TO FIRE THESE FASTENERS ARE SHOWN BELOW;



SPOTNAILS TS3832



SPOTNAILS SCN45



#### SHEET COLLATED (PLASTIC)

WILL NOT GIVE YOU ANY SHARP WIRE STICKING OUT OF THE PLYWOOD THAT WIRE COLLATED NAILS COULD.

DIVERGENT POINT—TWIST AS THEY ENTER THE TIMBER, CREATING GREATER STAPLE RETENTION.

CHISEL POINT—DESIGNED TO GO STRAIGHT INTO THE TIMBER WITH EASE.

#### **SPOTNAILS DIVERGENT POINT (DC) STAPLE SIZES AVAILABLE;**

55DC (16mm) / 66DC (20mm) / 77DC (22mm)

#### **SPOTNAILS SHEET COLLATED NAIL SIZES AVAILABLE;**

2.0 X 19mm / 2.0 x 22mm / 2.0 x 25mm / 2.0 x 28mm



### GUIDE TO FIXING

SPOTNAILS DIVERGENT POINT STAPLES MUST BE STAPLED ACROSS THE GRAIN ON TOP.

BOTH STAPLE OR NAIL SHOULD BE 150mm (6in) CENTRE STARTING IN THE MIDDLE AND WORKING BOTTOM TO TOP GIVING YOU A CROSS (LIKE ST GEORGES FLAG).

BOTH STAPLE OR NAIL SHOULD BE ON THE OUTSIDE EDGE 12mm (1/2in) AWAY FROM EDGE AND THEN 100mm (4in) APART.